





How to:

Reset High Scores on Stern Pinball

1. Unlock and open coin door in front of machine.



2. Locate 'Menu' button and push to enter 'Service Menu'. Press 'Menu' button once more to enter 'Standard Adjustments Menu'.





How to:

Reset High Scores on Stern Pinball

3. Press the Volume + button to scroll to 'Adjustments'.



4. Press 'Menu' Button to select 'Adjustments'.

5. Press 'Menu' Button again to select 'SPI'.






How to:


Reset High Scores on Stern Pinball

6. Use the Volume + button to scroll through until you see the standard adjustment for 'Grand Champion Score'.



7. Press 'Menu' button to enter setting. Use Volume +/- to adjust score. Press 'Service/Credit' button to exit setting.

8. Using the Volume +/- navigate to next High Score and repeat step #7.





How to:

Reset High Scores on Stern Pinball

9. Once all High Scores are set to desired levels, simply press the 'Service/Credit' button until you exit the Service Menu.

