




How to:

Perform a Switch Test on Stern Pinball

1. Open coin door to locate service buttons.
2. Press the black “Menu” button twice to enter the service menu.



3. “DIAG” will be highlighted, Press the menu button again to enter the Switch Test menu.





How to:

Perform a Switch Test on Stern Pinball

4. "TEST" will be highlighted with "SWITCH TEST" underneath.
5. Press the Menu button again, "SWITCH TEST PRESS ANY SWITCH TO BEGIN" will appear on the screen.



6. Press the Lockdown Switch to begin the test.



How to:

Perform a Switch Test on Stern Pinball



7. Press the lockdown Switch while observing the screen, you should hear a ding, a box should appear on the left side of the center bar and the brightness of the menu will change.



How to:

Perform a Switch Test on Stern Pinball



8. If switch fails, remove the lock bar, locate the lockbar switch.



9. Press on the actuator with your finger while observing the screen, if the switch activates then the bottom switch blade needs to be bent up.

10. If the switch is constantly on then the top switch actuator blade will need to be bent up.